

Solvti IoT Box Configuration Guide




Languages


PL	2
ENG	5

PL Instrukcja konfiguracji Odoo IoT Box


1. Aktywuj aplikację **Internet Rzeczy** na swojej instancji Odoo.



2. Wejdź do modułu **IoT Box**. Kliknij połącz.



3. W wyświetlonym oknie kliknij „**Kopia**” aby skopiować wyświetlony token.



4. Sprawdź **adres IP** swojego Solvti IoT Boxa

Gdy masz dostęp do monitora

- I. Podłącz IoT Boxa do monitora
- II. Podłącz swojego IoT Boxa do sieci
 - Za pomocą wejścia Ethernet
 - Za pomocą Wi-Fi
 - a. Podłącz urządzenie IoT do źródła zasilania i odczekaj kilka minut, aż się włączy.
 - b. Otwórz ustawienia Wi-Fi komputera i wybierz sieć IoT Box. Nazwa sieci jest w formacie IoTBox-xxxxxxxxxxx(gdzie xxxxxxxxxxxxto unikalny identyfikator).
 - c. Połącz się z siecią Wi-Fi urządzenia IoT Box i zaloguj się. Twoja przeglądarka powinna otworzyć się automatycznie i przekierować na stronę główną urządzenia IoT Box .
 - d. Na wyświetlonym ekranie zobaczysz adres IP.




Gdy nie masz dostępu do monitora

Pobierz bezpłatną aplikację na swój komputer:

- Aplikacja dla systemu macOS: IP Scanner
: <https://apps.apple.com/pl/app/ip-scanner/id6443819966>

- Aplikacja dla systemu Windows: [Advanced IP Scanner — Pobierz bezpłatny skaner sieciowy](#)


Aplikację należy pobrać ale nie trzeba jej instalować, wystarczy uruchomić. Następnie należy kliknąć „**skanuj**”. Odnaleźć IoT Box i spisać jego IP.



5. Wpisz w wyszukiwarkę internetową np. Google Chrome **adres API**, który wyświetla nam się jako przypisany do tego IoT Boxa.
6. W wyświetlonym oknie w przeglądarce nazwij swój Solvti IoT Box. W miejsce server tokena wklej token **skopiowany z Odoo** (punkt 3). Kliknij „**next**”.




7. W aplikacji IoT Box zobaczysz podłączony swój Solvti IoT Box.




ENG Instruction of configuration Solvti IoT Box


1. Activate the Internet of Things app on your Odoo instance



2. Go to the IoT Box module. Click Connect.



3. In the window that appears, click Copy to copy the displayed token



4. Check the IP address of your Solviti IoT Box

When you have access to a monitor:

I. Connect the IoT Box to a monitor.

II. Connect your IoT Box to the network:

- Using the Ethernet port
- Using Wi-Fi:
 - a. Plug the IoT device into a power source and wait a few minutes for it to start.
 - b. Open your computer's Wi-Fi settings and select the IoT Box network. The network name has the format *IoTBox-xxxxxxxxxx* (where *xxxxxxxxxx* is a unique identifier).
 - c. Connect to the IoT Box Wi-Fi network and log in. Your browser should open automatically and redirect to the IoT Box home page.
 - d. The displayed screen will show the IP address.




When you don't have access to a monitor:

I. Download a free application on your computer:

- For macOS: **IP Scanner**
<https://apps.apple.com/pl/app/ip-scanner/id6443819966>
- For Windows: **Advanced IP Scanner**: [Advanced IP Scanner — Pobierz bezpłatny skaner sieciowy](#)

You don't need to install the application, just run it. Then click **Scan**, find the IoT Box and note down its IP address.



5. Enter the **IP address** of the IoT Box in your web browser (e.g., Google Chrome).

6. In the window that opens in the browser, name your **Solvti IoT Box**. In the **Server Token** field, paste the token copied from Odoo (step 3). Click **Next**.



7. In the IoT Box app, you will now see your connected **Solvti IoT Box**.

